



Infor Forcam MES FFAuth: Unified Login for Infor Forcam MES

Version 5.11

Copyright © 2022 Infor

Important Notices

The material contained in this publication (including any supplementary information) constitutes and contains confidential and proprietary information of Infor.

By gaining access to the attached, you acknowledge and agree that the material (including any modification, translation or adaptation of the material) and all copyright, trade secrets and all other right, title and interest therein, are the sole property of Infor and that you shall not gain right, title or interest in the material (including any modification, translation or adaptation of the material) by virtue of your review thereof other than the non-exclusive right to use the material solely in connection with and the furtherance of your license and use of software made available to your company from Infor pursuant to a separate agreement, the terms of which separate agreement shall govern your use of this material and all supplemental related materials ("Purpose").

In addition, by accessing the enclosed material, you acknowledge and agree that you are required to maintain such material in strict confidence and that your use of such material is limited to the Purpose described above. Although Infor has taken due care to ensure that the material included in this publication is accurate and complete, Infor cannot warrant that the information contained in this publication is complete, does not contain typographical or other errors, or will meet your specific requirements. As such, Infor does not assume and hereby disclaims all liability, consequential or otherwise, for any loss or damage to any person or entity which is caused by or relates to errors or omissions in this publication (including any supplementary information), whether such errors or omissions result from negligence, accident or any other cause.

Without limitation, U.S. export control laws and other applicable export and import laws govern your use of this material and you will neither export or re-export, directly or indirectly, this material nor any related materials or supplemental information in violation of such laws, or use such materials for any purpose prohibited by such laws.

Trademark Acknowledgements

The word and design marks set forth herein are trademarks and/or registered trademarks of Infor and/or related affiliates and subsidiaries. All rights reserved. All other company, product, trade or service names referenced may be registered trademarks or trademarks of their respective owners.

Publication Information

Release: Infor Forcam MES 5.11

Publication date: September 19, 2022

Contents

About this guide	5
Intended audience	5
Organization.....	5
Related documents.....	5
Contacting Infor.....	5
Chapter 1 Concept	6
Background.....	7
Timeout.....	8
Chapter 2 Switching between Workbench and Office	9
URL in a Tile	10
URL in System Configurations	10
Chapter 3 Security Certificate (HTTPS)	11

About this guide

Intended audience

Organization

This table shows the chapters of the guide:

Section	Description

Related documents

You can find the documents in the product documentation section of the Infor Support Portal, as described in "Contacting Infor" on page 5.

Contacting Infor

If you have questions about Infor products, go to Infor Concierge at <https://concierge.infor.com/> and create a support incident.

The latest documentation is available from docs.infor.com or from the Infor Support Portal. To access documentation on the Infor Support Portal, select **Search > Browse Documentation**. We recommend that you check this portal periodically for updated documentation.

If you have comments about Infor documentation, contact documentation@infor.com.

Chapter 1 Concept

FFAuth is the single sign-on solution from Infor Forcam MES. The user can log on via one of the two modules Workbench or Office and is automatically logged on to the other module without having to enter the user data again. The registration is taken over by FFAuth.

The aim is to give the user the feeling of navigating through a single application. The main entry point is the Workbench with its tile navigation. A tile takes the user directly to the Office module and redirects him or her back to the Workbench.




Fig. 1: Transmission of login information via FFAuth

FFAuth is a service that centrally manages login information. If, for example, the user logs on via the Workbench, he or she is first logged on centrally to FFAuth. The information is then transferred to the Workbench. If the user then calls the Office, the information is transferred and the user is logged on automatically.

The information includes the user's logon data and status. The language settings are also transferred, but the exchange takes place directly between the modules.

If the user logs off via one of the modules, he is also logged off via the other.

Note: In order to use FFAuth, cookies must be accepted in the browser used.

The login screen of the modules optically differs slightly when using FFAuth.



Fig. 2: Workbench login screen without (left) and with (right) FFAuth

Note: The login screen is displayed in the browser language used.

Background

Workbench, Office and FFAuth are three independent applications. When a user logs on via the Workbench, the logon data is stored centrally in FFAuth. If the user now opens the Office, this starts a request to FFAuth and asks whether the user is already logged in. If the result is positive, the user is automatically logged in to the Office. The check takes place without any significant time delay.

If the user logs off from one module, the logoff information is also transferred to the other module and the user is also logged off there.

Language settings are also transferred, but not managed by FFAuth. The exchange takes place directly via the modules: If a language is selected in one module, the other module is informed and changes the language. If a user is logged in to the Workbench in the language **English (US)**, for example, this setting is transferred to the Office and it also starts in English.

If Workbench and Office are open in one browser at the same time, the language setting is only transferred from one module to the other after the second module has been refreshed. In the example above, the user must reload the Office tab. If the user logs off from the Office, the previous language setting is reloaded.




Fig. 3: Transmission of language settings directly via modules

Timeout

The central login at FFAuth is valid for 24 hours.

When the user logs on to the Workbench, a session is started that is open for 24 hours. The user is logged off automatically after the session has expired.

For example, if the user logs off after 20 hours, the session ends. If the user logs on again, a new 24-hour session is started. If the user then calls the Office module after 20 hours, a new, separate session is started. However, the session in the Office module already expires after 30 minutes.

Chapter 2 Switching between Workbench and Office

FFAuth brings the Workbench and Office modules closer together. The navigation between the modules is seamless and does not require a new login. The Workbench serves as an entry point. In the tile navigation, a URL can be configured so that it calls the Office in the same window. If the user clicks on the home icon in the office or uses the back function of the browser, he or she returns to the Workbench. FFAuth gives the user the feeling of using a single application.




Fig. 4: Seamless navigation using the Workbench

URLs must be stored in two places for navigation between the Workbench and Office.

URL in a Tile

The tile navigation of the Workbench is flexibly adaptable. The tiles can be freely configured. For detailed instructions, see the **Master Data and System Configuration** manual.

To navigate to the Office, the address of the module must be entered in a URL tile:




Fig. 5: Entering the Office address in the URL tile

URL in System Configurations

To return to the Workbench from the Office by clicking on the home icon or the back function of the browser, the Workbench address must be entered in the system settings:

System	Identifie	Value
FORCAM FORCE™	Workbench configuration	
Configurations	Url	http://fctestfactory04.northeurope.cloudapp.azure.com:15080/ffworkbench
General		
Modules		
Runtime		
Workbench		
Url		
Database Connection		

Fig. 6: Entering the Workbench address in system configurations

Chapter 3 Security Certificate (HTTPS)

FFAuth uses the transport encryption HTTPS. It is possible to use an existing certificate. This must be provided by the customer. You can also generate your own certificates. However, the browser classifies these as insecure.

If a self-generated certificate is used, the browser displays an "insecure connection" when a module is called. In any case, the warning of insecurity only appears when the module is called for the first time.



Fig. 7: Security warning on Google Chrome